



No.7000

リビングチェア




L7000肘無
〔W146SH39・42〕




S7000肘無〔W173SH39・42〕

側面




右側面

S7000右肘〔W176SH39・42〕




左側面



右側面


S7000左肘〔W176SH39・42〕

左側面



SL7000カウチ
〔W73SH39・42〕

側面



7000スツール
〔W73SH39・42〕

側面